



# Ersatzteile ZS 30 / W



Montage-Werkzeug  
 Assembling tool



A	RBA1 15403
B	RBK3 28823

2 Krümmer	Teile-Nr.
2 Elbow	Part-No.
ZS 30	RB02 28800
ZS 30W	RB02 28820

Düsen Nozzle	1  Teile-Nr. 1  Part-No.	3  Teile-Nr. 3  Part-No.
φ3,5	RBA1 28862	
φ4,0	RBA1 28843	
φ4,2	RBA1 28844	
φ4,5	RBA1 28845	RTL5 28855
φ4,8	RBA1 28846	RTL5 28856
φ5,2	RBA1 28847	RTL5 28857
φ6,0	RBA1 28848	